





					WEIGHT:			SCALE:1:2		SHEET 1 OF 5		
Q.A					MATERIAL		astic	DWG NO.	DWG NO.			A4
MFG												
APPV'D									Dasc II	α		
CHK'D	Base Track										`k	
DRAWN												
	NAME	SIGI	NATURE	DATE				TITLE:				
SURFAC TOLERA LINEAI ANGU	R:						EDGES					
UNLESS OTHERWISE SPECIFIED: FINISH: DIMENSIONS ARE IN MILLIMETERS						DEBUR AND BREAK SHARP	DO NOT SCALE DRAWING REVISION					







DIMENSI	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MILLIMETERS SURFACE FINISH: TOLERANCES: FINISH:						DEBUR AND BREAK SHARP EDGES	DO N	DO NOT SCALE DRAWING REVISION			
LINEAR ANGU												
	NAME	SIGI	NATURE	DATE				TITLE:				
DRAWN												
CHK'D								Mac	hined C	uvatta		
APPV'D								Maci		OVEITE		
MFG												
Q.A					MATERIAL	:		DWG NO.	04	,		
				1			04					
					WEIGHT:			SCALE:1:2 SHEET 4 O		EET 4 OF 5	OF 5	



Assembly protocol of PIP

- Step 1: Insert Cuvette into the square hole of the Base Track
- Step 2: Insert L Shape Adapting Rod with Spring and Fix Screw to the Cuvette from the top through the slot opening on the top of the Base Track
- Step 3: Mount and fix the Micrometer Drive at the top hole, by using screw on the side
- Step 4: Assemble Laser Diode and Iris Diaphragm into Laser Holder
- Step 5: Assemble Cylindrical Lens into Lens Holder
- Step 6: Mount tow holders together with Screw-Nuts Set
- Step 7: Slide two holders into Base Track
- Step 8: Mount the device onto the inverted microscopy object stage
- Step 9: Open the cap of Cuvette from the side, mount the Sample Tube onto the Adapting Rod.
- Step 10: Seal the cuvette with the cap and fill the refractive index matching water in using syringe
- Step 11: Turn on the laser diode, observe the sample from eye-piece. Finely tune the position of cylindrical lens till the light sheet focus on the sample.